



## *FLEXIBLE EDGING SYSTEM*

### **INSTRUCTIONS FOR USE**

1. SNAP EACH 2.4M LENGTH DOWN THE MIDDLE TO SEPARATE THE LENGTHS
2. LAY WEED CONTROL MEMBRANE (IF REQUIRED)
3. LAY EACH LENGTH FLAT SIDE DOWN WITH PUNCHED TABS TO INNER AREA (I.E. AREA BEING COVERED WITH AGGREGATE)
4. CONNECT EACH 2.4M LENGTH OF THE EDGING SYSTEM USING AN INTERNAL CONNECTOR
5. TO CUT LENGTHS OF THE EDGING SYSTEM (IF REQUIRED) USE A HAND SAW
6. SECURE THE EDGING SYSTEM INTO THE GROUND USING SNAKE EDGE 150 GALVANISED NAILS - AFFIXED THROUGH THE HOLES IN THE TABS - CREATE THE SHAPE REQUIRED (EITHER CURVED OR STRAIGHT) WHILST SECURING THE EDGING SYSTEM INTO THE GROUND
7. LAY AGGREGATE TO THE TOP OF THE EDGING SYSTEM, LEVEL AND COMPACT
8. LAY ARTIFICIAL GRASS, ENSURE THE ARTIFICIAL GRASS COVERS ALL OF THE SERRATED SURFACE OF THE EDGING SYSTEM
9. AFFIX THE ARTIFICIAL GRASS TO THE SERRATED SURFACE OF THE EDGING SYSTEM USING SNAKE EDGE ADHESIVE - AFFIX SCREWS (IF REQUIRED) TO HELP WITH ADHESION

**SnakeEDGE.COM**

**0114 251 4291 / 01909 771 278**

**SnakeEDGE11@GMAIL.COM**